







## Ana Ölçüler / Montaj Ölçüleri



## Dekoratif Sarkıt Armatürler MONTAJ ŞARTNAMESİ



- Armatür çalışma gerilimi ile şebeke gerilimi aynı olmalıdır. (220-240V/50-60Hz)
- Armatürün elektriksel bağlantısı yapılmadan önce mutlaka şebekenin gerilimi ve bağlantı çalışmaları yapıldığına dair pano üzerine bir levha asılmalıdır.
- Armatürün sıva üstü montajının yapılabilmesi için rozansın askı aparatın tavana 2 vida yardımı ile sabitleyiniz.
- Armatürün elektriksel bağlantısını (klemens) yapınız.
- Ardından rozansı askı aparatına yerleştirip 2 vida yardımı ile rozansı sabitleyiniz.
- Bağlantıların doğru olup olmadığını kontrol ediniz.
- Armatüre enerji veriniz.




## Güvenlik Uyarıları!

- Armatür montajını deneyimli ve ehliyetli bir elektrikçiye yaptırınız
- Kesinlikle tiner ve benzeri yanıcı, zarar verici malzemeler kullanmayınız
- Kurulum ve bakım işlemlerinden önce şebeke elektiriğini kesiniz
- Ürünü 220-240V AC/50-60Hz şebeke geriliminde kullanınız
- Armatür temizlerken nemli bir bez kullanınız
- Bağlantıların sıkı ve doğru olup olmadığını kontrol ediniz





\*Güncel ürün bilgileri için [www.pelsan.com.tr](http://www.pelsan.com.tr) adresini ziyaret edebilirsiniz.

# Decorative Pendant Luminaires


## Main Dimensions / Installation Dimensions



## Decorative Pendant Luminaires INSTALLATION SPECIFICATIONS



- Operating voltage of the luminaire and the mains voltage must be same.  
(220 - 240V / 50 - 60 Hz)
- Before the electrical connection, a plate MUST BE visibly attached to the beam box demonstrating the mains voltage and stating that the electrical connection works continue.
- For the surface mounting of the luminaire anchor the bracket of the rozans to the ceiling with the aid of 2 screws.
- Make the electrical connections (terminal) of the luminaire.
- Then place the rozans into the bracket and fix it with the aid of 2 screws.
- Check whether the connections are accurate.
- Energise the luminaire.



## Safety Warnings!

- The luminaire should be installed by an experienced and licensed electrician
- The grid electricity should be turned off before installation and maintenance
- The luminaire should be cleaned with a soapy cloth
- Thinner or similar flammable, harmful cleaning substances should be avoided
- The product should be operated at a 220-240 V AC / 50-60 Hz grid
- The tightness and the correctness of the connections should be checked

\*Please visit [www.pelsan.com.tr](http://www.pelsan.com.tr) for current product information